



ISO 9001:2000 CERTIFIED

BAR'S LEAKS TECHNICAL BULLETIN

Tech Bulletin #: TB-HJ12-1

Page 1 of 1

Date 1st Issued: May 31, 2006

Date Revised: November 27, 2007

Bar's Leaks Jack Oil With Stop Leak

Part #: HJ12

JACK OIL WITH STOP LEAK

Bring life back to old jacks and prevent leaks and seepage on newer jacks. Reconditions seals to stop current and future leaks. Works in all floor and bottle jacks. Mixes with all approved hydraulic jack oils. Includes easy fill cap. Great for topping off. Also works with all snow plow fluids



MOST COMMON JACK PROBLEMS	THE SOLUTION, BAR'S LEAKS JACK OIL WITH STOP LEAK
<ul style="list-style-type: none"> Leaks Worn/Dry Seals 	<ul style="list-style-type: none"> Stops Leaks Prevents Leaks Conditions Seals

DIRECTIONS

- Clean area around filler cap. Fill jack to proper level. Cycle jack by lifting and releasing a few times to release any air caught in system. Leaks usually stop in a few days of normal usage. If leak continues, repair may be required.

Part Number:	HJ12
UPC Item:	0 46087 00044 1
UPC Case:	1 00 46087 01000 3
Bottle Size:	12 fl. oz. (355 ml)
Bottle Dimensions:	3.4 x 1.8 x 9.3
Bottle Cube:	57
Case Pack:	6 bottles per case
Case Size:	7.3 x 6.1 x 9.6
Case Cube:	427
Case Weight:	6 pounds
Pallet:	TI 35 HI 6 Total 210
Pallet Height:	64 inches
Tariff Code:	2710.19.3020

INGREDIENTS

- Hydrotreated Fluid
- Seal Swell
- Seal Conditioners

Dosage

1 bottle treats two to three quarts of fluid.